

Fitting algorithm for Coincidence histograms in Offline

Mauricio Suárez Durán and Ioana C. Mariş


IIHE-ULB

July 28, 2022



How to fit the coincidence histograms?

Let's start with height coincidence histograms, and fitting a second order polynomial




So, the first task is to identify wrong height coincidence histograms.

Identifying wrong height coincidence histograms


Using the symmetry of the coincidence histograms

- Find the bin with the maximum of counts (binMax)
- From bin 25 until 100 (beginning of big-bins), counts the number of entries leftward and rightward, respect the binMax.
- Plot the distribution of $(\text{EntrLeftward} - \text{EntrRightward}) / \text{TotEntr}$.



Identifying wrong coincidence height histograms: results

Using the symmetry of the height coincidence histograms



Setting the properly range to fit height coincidence histograms

Using the symmetry of the height coincidence histograms





- ▶ Find the bin with the maximum of counts (binMax)
- ▶ From binMax, fit a second order polynomial from binMax - n to binMax + n.
- ▶ Check for the distribution of χ^2 , error of fit as a function of the number of degree of freedom.

A temporary algorithm was implemented in the SdHistogramFitterKGB.cc module in order to find the best range:

```
if ( cntsLeft-cntsRight/totCnts < 0.14 ) {  
    for ( int nFADC=8; nFADC<100; nFADC+=4 ) {  
        [...]  
        MakeQuadraticFitter(coinciPeakHisto, binMax - nFADC, binMax + nFADC).GetFitData(qf);  
        [...]  
    }  
}
```

Setting the properly range to fit height coincidence histograms: results




Using the symmetry of the height coincidence histograms



Algorithm to fit height coincidence histograms



1. Find the bin with the maximum of counts (binMax)
2. From binMax, fit a second order polynomial to range: binMax-44 (44 is equivalent to 19 Ndof).
3. Check if the previous range fulfill that: $\sigma/lpk < 0.05$ and $\chi^2/Ndof < 2.0$
4. If not, steps 2 and 3 are repeated for the range: binMax-48.
5. The steps 2 and 3 are repeated until for some range the step 3 is fulfilled or until the final range of binMax-80 is reached. If it is the last case, so lpk gets zero.

Results for height pulse histograms




Results for height pulse histograms

Outliers



Algorithm to fit height coincidence histograms: results






Doing for charge coincidence histograms

Checking for wrong charge coincidence histograms

Using the symmetry of the coincidence histograms

- ▶ Find the bin with the maximum of counts (binMax)
- ▶ From bin 25 until 100 (beginning of big-bins), counts the number of entries leftward and rightward, respect the binMax.
- ▶ Plot the distribution of $(\text{EntrLeftward} - \text{EntrRightward}) / \text{TotEntr}$.

Checking for wrong charge coincidence histograms: results



Not wrong charge coincidence histograms, as there are for pulse height ones.

Setting the properly range to fit charge coincidence histograms

Using the symmetry of the charge coincidence histograms





- ▶ Find the bin with the maximum of counts (binMax)
- ▶ From binMax, fit a second order polynomial from binMax - n to binMax + n.
- ▶ Check for the distribution of χ^2 , error of fit as a function of the number of degree of freedom.

A temporary algorithm was implemented in the SdHistogramFitterKGB.cc module in order to find the best range:

```
for ( int nFADC=16; nFADC<1000; nFADC+=8 ) {  
    [...]  
    MakeQuadraticFitter(coinciChargeHisto, binMax - nFADC, binMax + nFADC).GetFitData(qf);  
    [...]  
}
```

Setting the properly range to fit charge coincidence histograms: results




Using the symmetry of the height coincidence histograms



Algorithm to fit charge coincidence histograms


1. Find the bin with the maximum of counts (binMax)
2. From binMax, fit a second order polynomial to range: binMax-296 (296 is equivalent to 71 Ndof).
3. Check if the previous range fulfill that: $\sigma/lpk < 0.05$ and $\chi^2/Ndof < 2.0$
4. If not, steps 2 and 3 are repeated for the range: binMax-304.
5. The steps 2 and 3 are repeated until for some range the step 3 is fulfilled or until the final range of binMax-496 is reached. If it is the last case, so lpk gets zero.

Results for charge coincidence histograms



Results for charge coincidence histograms

Outliers



Event 66926832 :-)

Time (UTC): 2022/2/9 19:37:52

Time (GPS): 1328470690 s 873134000 ns

Trigger: 3TOT & 4C1; 6T5 5T5

Stations: 8 (Acc: 2, Bad: 6)

Full reconstruction (4.5)

$E = (3.31 \pm 0.38 \pm 0.13) \times 10^{18} \text{ eV}$

$(\theta, \phi) = (58.4 \pm 0.4, 250.7 \pm 0.4) \text{ deg}$

$(x, y) = (-9.78 \pm 0.06, 14.93 \pm 0.12) \text{ km}$

$S1000 = 9.1 \pm 1.0 (\pm 0.3) \text{ VEM}$

$\beta = -1.63 (\pm 0.29), \gamma = -0.01, r_{\text{opt}} = 921. \text{ m}$

radius = $14.16 \pm 1.90 \text{ km}$

Monitoring

average stations age: 14.3 yr

